


Double Broadcast Solid Quartz Floor System



Step 1 Prep concrete to CSP3 Profile by Grinding and/or Shot Blasting

Step 2 Patch Cracks and Spalls using ResinForce® EasyMend®, grind flush to floor

Step 3 Apply ResinForce® MVB Moisture Barrier Prime Coat (ResinForce® FlakeShield™ MVB)
(100 sq. ft. / gal.)

Step 4 Within recoat window of MVB, apply first base broadcast coat of ResinForce® 100% Solids Pigmented Epoxy (RF100)
(100-120 sq. ft. / gal.)

Step 5 Full Broadcast Spectra Quartz to rejection, sweep and reclaim loose quartz, vacuum thoroughly
(Approximately 1 pound per sq. ft.)

Step 6 Apply second base broadcast coat of ResinForce 100% Solids Pigmented Epoxy (RF100)
(90-100 sq ft per gallon)

Step 7 Full Broadcast Spectra Quartz to rejection, sweep and reclaim loose quartz, vacuum thoroughly
(Approximately 1 pound per sq ft)

Step 8 Option 1 – Apply 100% Solids Pigmented Epoxy (RF100) Grout Coat (90-110 sq ft per gallon).
Then if desired, apply ResinForce® High Wear Aliphatic Urethane top coat.
(250-350 sq ft per gallon)

Option 2 – Apply ResinForce EasyPoly Pigmented Polyaspartic grout and top coat in one.
(90-110 sq ft per gallon)